

DOK240-C

CHEMICAL 240 LITRE WHEELY BIN SPILL KIT

SPILL KIT ITEM	INSTRUCTIONS FOR USE
OPTISORB 40 30 Litre (15Kg) bag PART# OPT4030 x 2	USE OPTISORB40 TO ABSORB THE SPILL <ul style="list-style-type: none">» Spread the OPTISORB40 onto and in front of the spill. Push it into the spill with a broom or shovel.» The OPTISORB40, although small in size, will absorb up to 30 litres of liquid. It should be used to absorb and solidify large volumes of spilt liquid.
MINIBOOMS 3.0m x 75mm PART# CB7530 x 6	USE BOOMS TO CONTAIN OR DIVERT THE SPILL <ul style="list-style-type: none">» Place downhill from spill if ground slopes.» Overlap ends for increased length.» Surround leaking drums and containers to prevent the spill from spreading.» Protect drains by placing booms in front of or around the drain.» Divert the spill away from drains, stock or equipment to an area where the spill can be cleaned up.» Use booms to absorb the spilt chemical.
PADS 450mm x 450mm x 200gsm Regular thickness PART# CPL4545 x 100	USE PADS TO ABSORB AND CLEAN UP THE SPILL <ul style="list-style-type: none">» Use pads to wipe down clothing, hands, floor, containers, drums etc., contaminated by the spill.» Place pads behind the booms to absorb any seepage from under the booms and under leaking pipes or valves.
PILLOWS 460mm x 460mm PART# CPI6035 x 2	USE PILLOWS TO ABSORB LARGER SPILL AREAS <ul style="list-style-type: none">» Place pillows behind the booms to absorb the bulk of the spill. Ideal for under leaking pipes, valves, gaskets or other leaking equipment.
DISPOSAL BAGS + cable tie 800 x 510mm PART# DBS x 8 cable tie x 8	FOR USE IN THE CLEAN UP STAGE <ul style="list-style-type: none">» Place used absorbents into bag. Fill only half full, then tie off with knot for transportation or movement.
PVC GLOVES PART# PVCG x 2	<ul style="list-style-type: none">» Use when handling spills
DUSTPAN and BRUSH PART# DPSS x 1	<ul style="list-style-type: none">» Use when handling spills